


Disassembly and Recycling Instructions


Dash 1130, 1131
Tools Required:




Safety Glasses



Metric Allen
Wrenches



Hammer



Wrenches/Ratchet

1. Remove Casters/Glides from frame. Discard Casters/Glides
2. Separate the Back from the frame then recycle.
3. Separate the Seat from the frame then recycle.
4. Face the chair down and use the hammer to remove the arms. Discard Arms
5. After all parts are removed then recycle the frame.



Back
Polypropylene



Arms
Polypropylene



Seat
Polypropylene



Frame
Cold Rolled Steel



Casters, Glides
Polypropylene, Nylon, ABS



= Recyclable Material Content