


Vito

INS-P3480-PAC


ASSEMBLY INSTRUCTIONS

9to5
seating

PARTS




Back (x1)




Seat (x1)



Arms (x2)



Base (x1)



Cylinder (x1)



Casters (x5)

TOOLS



Allen Wrench (x1)
(attached to the
cylinder box)

HARDWARE



M6*35 bolts for the arms (x6)




M8*25 bolts for the Back (x3)

All hardware comes pre-attached in the back and/or seat.
Missing parts or hardware? Call 888.925.SEAT


STEP 1

Attach the casters and cylinder to the 5-star base.



1A. Firmly press the stems
of 5 casters into the 5 holes
in the base.


1B. Insert cylinder into
the center hole.



STEP 2

Attach the arms to the seat.

2A. Invert the seat, fabric side down, and remove the M6*35 bolts for the arms from the seat with the Allen wrench. There are 6 bolts total (3 per arm).




2B. Adjust the left and right arms to be symmetrical, then reattach the bolts to secure the arms.

STEP 3

Attach the back to the seat.

3A. Using the Allen wrench, remove the 3 M8*25 bolts from the back.




3B. Place the back plate under the seat as shown, aligning the holes. Using the Allen wrench, reattach the bolts from the top.

STEP 4

Join the back and seat with the cylinder and base.

Insert the assembled back/seat unit onto the cylinder, which was placed in the base in Step 1. Press down firmly to secure.



Part of the Flokk Group

9to5
seating

@NCE
from 9to5 Seating

PHONE 888.925.SEAT 9to5seating.com
3211 Jack Northrop Ave. Hawthorne, CA 90250

©2025 9to5 Seating

Updated 8/27/2025