


# Disassembly and Recycling Instructions

Dash 1090, 1091


Tools Required:




Safety Glasses



Metric Allen  
Wrenches



Hammer



Wrenches/Ratchet

1. Remove Casters/Glides from frame. Discard Casters/Glides
2. Separate the Back from the frame then recycle.
3. Separate the Seat from the frame then recycle.
4. Face the chair down and use the hammer to remove the arms. Discard Arms
5. After all parts are removed then recycle the frame.



**Back**

Polypropylene



**Arms**

Polypropylene



**Seat**

Polypropylene



**Frame**

Cold Rolled Steel



**Casters, Glides**

Polypropylene, Nylon, ABS



= Recyclable Material Content