


W2

Weight Balanced
1 Paddle


Control Guide

Auto-Balance tension adjustment utilizes the weight of the user to balance resistance of the back. Sensing can be adjusted to suit individual preference. 3:1 back to seat synchronous movement with 4 position back-travel limiting lock.


Tilt Tension Control Knob:
Turn knob clockwise to tighten the tilt tension and counter clockwise to loosen tilt tension.



Right when seated



4 Position Back Travel Control Knob :
Gently apply pressure to lock while seated, turn the knob counter clockwise to release the back . Angle the back into one of the four lock position then turn the knob clockwise to lock the back into place.



Seat Height Lever:
Lift and hold the lever to raise the seat. Release the lever to lock at the desired height . Lift and hold lever while applying weight on seat to lower seat height.