



Disassembly and Recycling Instructions

Remy 2820 Rocking Stool


Tools Required:




Safety Glasses



Screw Driver



Battery Drill



Hammer

1. Remove Pedestal Weight from Pedestal Base Using Battery Drill. Discard Pedestal Weight
2. Separate Gas Lift from the Seat Plastic by Hammering seat plastic and pulling on Gas Lift.
3. Discard Gas Lift.
4. Separate the Seat Plastic from Seat by using a screw driver to pry off the seat.
5. Discard Seat .



Seat

Polypropylene, Polyurethane foam



Seat Plastic

Polypropylene

Gas Lift

Polypropylene, Steel



Pedestal Base

Polypropylene

Pedestal Weight

Rubber and Steel



= Recyclable Material Content