


Disassembly and Recycling Instructions

Cosmo 3250-GT


Tools Required:



Safety Glasses



Metric Allen
Wrenches



Wrenches/Ratchet

1. Remove Casters/Glides from frame. Recycle Casters/Glides
2. Separate the Back from the frame then Discard.
3. Separate the Seat from the frame then Discard.
4. Face the chair down and use a screwdriver to remove the arms. Recycle Arms
5. After all parts are removed then recycle the frame.



Back

Polypropylene, Polyester



Arms

Polyurethane foam, Steel Rod

Seat

Plywood, Polyurethane foam



Frame

Cold Rolled Steel



Casters, Glides

Polypropylene, Nylon, ABS



= Recyclable Material Content