


X2


For Cosmo
Only

Control Guide

Recline with a synchro back and seat movement featuring a 2:1 back to seat tilt ratio. Reduced rise of front seat edge. 11 position multi-lock with built-in safety return feature. Integrated seat slider and forward pitch adjustment.



Seat Height Lever:
Twist the lever to raise the seat,
Release the lever to lock at the
desired height . Lift and hold
lever while applying weight on
seat to lower seat height.



Tilt Tension Control Knob:
Pull the knob outward for
easy access and turn knob
clockwise to tighten the tilt
tension and counter clock-
wise to loosen tilt tension.



**Back Multi-Lock W/ Safety
Release:**
Lift the lever up to release
the back . Angle the back
into desired lock position
then push the lever down to
lock the back into place.