

Y2


Synchro Tilt 2 Paddle

Control Guide

Recline with a synchro back and seat movement featuring a 2:1 back to seat tilt ratio. Reduced rise of front seat edge. 4 position multi-lock with built-in safety return feature and slide tension control.

Tilt Tension Control Knob:

Pull the knob out, away from center of seat, and turn knob clockwise to tighten the tilt tension and counter clockwise to loosen tilt tension.



Right when seated

Left when seated



Seat Height Lever:

Lift and hold the lever to raise the seat. Release the lever to lock at the desired height. Lift and hold lever while applying weight on seat to lower seat height.



Back Multi-Lock W/ Safety Release:

Gently apply pressure to lock while seated, lift the lever up to release the back. Angle the back into desired lock position then push the lever down to lock the back into place.